

Assembly and packaging instruction - Magnetic Filter

SAFETY



Risk of personal injury

Strong magnetic field, may cause interference with active implanted medical devices, e.g. pacemakers and defibrillators, or medical devices worn on the body, e.g. infusion pumps.

PEOPLE WITH PACEMAKER OR OTHER ACTIVE MEDICAL DEVICES MUST NOT ASSEMBLE OR PACK THE PRODUCT.

Note:

The magnetic bars have a very thin steel tube so it is not recommended to clamp the bar over the magnets. It is also difficult to use a tool since the powerful magnetic field.

1. Clamp the magnetic bar firmly in a vise (letting some mm of the bar protrude) with a rubber band (using a boa constrictor tool)/rubber pads concentrating the force to the most upper part of the bar. See photo below.
2. Apply Loctite 243 on the thread of the Strainer basket.
3. The perforated strainer is used as a grip for turning the screw. Momentum is limited by friction on the magnetic bar.



Packaging of Magnetic Filter (if sold separately)

1. Insert the magnetic bar in the cardboard-tubes in which they arrived.
2. Place the magnetic filter in the center* (in all directions) of a box (Boxxon 90695, Wellpapplåda E480 1160x200x200mm*). Fixate using tightly packed wrapped paper.

*The center positioning and the large size of the box is too guarantee a safe level of magnetic field outside the box.